




How to fold the best PowerUp paper airplane




1. Start with the printed template face up. Fold in half, the lower edge to the top edge.




2. Make an Arrow Head by folding the left edge to the bottom edge (both are marked by thick lines).




3. Turn over the model.




4. Repeat step 2. on this side.




5. Spread the paper (unfold only the center line).




6. Fold the right corner to the left; refer to the base of the triangle as your guiding line.



7. Bring both marked corners to the black dot.




8. Lock the corners by folding the little triangle on top of the two corners.




9. Lock the corners by folding the little triangle on top of the two corners.


10. Fold the model in half by aligning the wings. Note the dashed line in the lower wing.




11. Fold the wing down along the mentioned dashed line.




12. Turn the model over.



13. Fold the other wing and align it with the first wing.



14. Spread the wings to the sides.



15. Your airplane is ready!


The best Template for the PowerUp 2.0
Electric Paper Airplane Conversion Kit
Paper Type - 20lb stock
Paper size - US letter 8.5"X11"
Printer Setting - Scale 100% borderless
www.poweruptoys.com



Copyright © 2013 TailorToys L.L.C. All rights reserved.
PowerUp® is a trademark of TailorToys L.L.C.




[How to fold video](#)



Elevator

Wing folding line



Elevator

Rudder

Rudder